

# ROITHNER LASERTECHNIK GMBH


**1040 VIENNA** WIEDNER HAUPTSTRASSE 76 TEL. +43 I 586 52 43 -0, FAX. -44, OFFICE@ROITHNER-LASER.COM





## QL63D5SA

#### **TECHNICAL DATA**



### **Red Laser Diode**

#### **Features**

- InGaAIP laser diode
- Peak Wavelength: 635 nm Optical Ouput Power: 5 mW
- Package: 5.6 mm, with Photo Diode



#### **Electrical Connection**

| Pin Configuration   |   |  |
|---------------------|---|--|
| n-type PIN Function | 3 1   |  |
| 1 LD Cathode        |   |  |
| 3 PD Anode          | 2   |  |
|                     | n-type PIN Function 1 LD Cathode 2 LD Anode, PD Cathode |  |

### Absolute Maximum Ratings ( $T_C=25$ °C)

| <u> </u>                   | •                   |         |      |
|----------------------------|---------------------|---------|------|
| Item                       | Symbol              | Value   | Unit |
| Optical Output Power       | P <sub>o</sub> (CW) | 6       | mW   |
| LD Reverse Voltage         | V <sub>R</sub> (LD) | 2       | V    |
| PD Reverse Voltage         | V <sub>R</sub> (PD) | 30      | V    |
| Operating Case Temperature | T <sub>C</sub>      | -10 +50 | °C   |
| Storage Temperature        | T <sub>sta</sub>    | -40 +85 | °C   |

### Specifications (T<sub>C</sub>=25°C)

| Item                      |                  | Symbol                         | Min. | Тур. | Max. | Unit |  |  |  |
|---------------------------|------------------|--------------------------------|------|------|------|------|--|--|--|
| Optical Specifications    |                  |                                |      |      |      |      |  |  |  |
| Optical Output Power (CW) |                  | Po                             | ı    | 5    | -    | mW   |  |  |  |
| Peak Wavelength           |                  | $\lambda_{P}$                  | 630  | 635  | 640  | nm   |  |  |  |
| EWHM Poom Divorgonoo      |                  | θ∥                             | 6    | 8    | 12   | deg  |  |  |  |
| FWHM Beam Divergence      | $\theta_{\perp}$ | 28                             | 34   | 40   | deg  |      |  |  |  |
| Emission Point Accuracy   | Angle            | Δθ∥                            | -    | -    | ±1.5 | deg  |  |  |  |
|                           |                  | $\Delta 	heta_{\perp}$         | -    | -    | ±2.5 | deg  |  |  |  |
| Optical Distance          |                  | $\Delta X, \Delta Y, \Delta Z$ | -    | -    | ±60  | μm   |  |  |  |
| Electrical Specifications |                  |                                |      |      |      |      |  |  |  |
| Threshold Current         |                  | I <sub>th</sub>                | -    | 30   | 40   | mA   |  |  |  |
| Operating Current         |                  | l <sub>op</sub>                | -    | 34   | 50   | mA   |  |  |  |
| Operating Voltage         |                  | V <sub>op</sub>                | -    | 2.2  | 2.7  | V    |  |  |  |
| Monitor Current           |                  | I <sub>m</sub>                 | 0.1  | 0.15 | 0.5  | mA   |  |  |  |

The above specifications are for reference purpose only and subjected to change without prior notice.




# ROITHNER LASERTECHNIK GIRDH


WIEDNER HAUPTSTRASSE 76


TEL. +43 I 586 52 43 -O, FAX. -44, OFFICE@ROITHNER-LASER.COM



#### **Typical Performance Curves**











## ROITHNER LASERTECHNIK GIRDH


**WIEDNER HAUPTSTRASSE 76** 

TEL. +43 I 586 52 43 -O, FAX. -44, OFFICE@ROITHNER-LASER.COM












### ROITHNER LASERTECHNIK GIIDH

WIEDNER HAUPTSTRASSE 76 IO40 VIENNA AUSTRIA TEL. +43 I 586 52 43 -0, FAX. -44, OFFICE@ROITHNER-LASER.COM



#### Package Dimensons



#### Safety of Laser light

Laser Light can damage the human eyes and skin. Do not expose the
eye or skin directly to any laser light and/or through optical lens. When
handling the LDs, wear appropriate safety glasses to prevent laser
light, even any reflections from entering to the eye. Focused laser
beam through optical instruments will increase the chance of eye
hazard.



#### **Cautions**

#### 1. Operating methode

- This LD shall change its forward voltage requirement and optical ouput power according to temperature change. Also, the LD will require more operation current to maintain same ouput power as it degrades. In order to maintain output power, use of APC (Automatic Power Control) is recommended. Which use monitor feedback to adjust the operation current.
- Confirm that electrical spike current generated by switching on and off does not exceed the
  maximum operating current level specified herein above as absolute maximum rating. Also,
  employ appropriat countermeasures to reduce chattering and/or overshooting in the circuit.



#### 2. Static Electricity

• Static electricity or electrical surges will reduce and degrade the reliability of the LDs. It is recommended to use a wrist trap or anti-electrostatic glove when handeling the product.

#### 3. Absolute Maximum Rating

Active layer of LDs shall have high current density and generate high electric field during its
operation. In order to prevent excessive damage, the LD must be operated strictly below
absolute maximum rating.

